

SPARE PARTS LIST

MODEL NO. JN1601

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	266053-1	šroub 4x35=new266351-3	4	
002	159769-4	prevodová skřín	1	
003	331438-1	ROD	1	
004	212222-2	jehlové ložisko 1612	1	
005	322704-7	hrídel	1	
006	226286-0	SPUR GEAR 34	1	
007	253215-0	FLAT WASHER 8	1	
008	159758-9	víko prevodovky JN1601 INC. 10	1	
009	210005-4	kulic. ložisko 608DDW = old 2	1	
010	263002-9	vymezovací cep 4	1	
011	241875-0	= new 240039-3	1	
012	517513-9	rotor INC. 9,11,13,14	1	
013	681636-0	izolační podložka = old 68166	1	
014	211021-9	kulickové ložisko = new 21001	1	
015	421479-6	vymezovací kroužek	1	
016	857617-8	NAME PLATE JN1601	1	
017	159755-5	motorová skřín	1	
018	415303-3	páčka vypínace	1	
019	635013-8	stator	1	
020	415490-8	kryt statoru	1	
021	254002-0	klínek 3	1	
022	267133-6	podložka	1	
023	226123-8	ozubené soukolí JN1601	1	
024	266026-4	šroub 4x12 křížový 5103R	1	
025	344116-4	aretace	1	
026	256111-1	cep 6	1	
027	322703-9	držák razníku	1	
028	322702-1	držák razníku	1	
029	265880-3	aretací šroub M5	1	
030	*****	*****	***	*****
031	A-15051	matrice	1	
032	322701-3	držák matrice	1	
033	266080-8	šroub M 3	2	
034	322748-7	matice JN1601	1	
035	266060-4	TAPPING SCREW 4x65	2	
036	819063-3	etiketa Makita	1	
037	643922-7	držák uhlíku	2	
038	191940-4	uhlíky CB-411 = old 191938-1	1	
039	643550-8	víčko uhlíku	2	
040	651418-4	vypínac ST115A-40=new651428-	1	
041	233071-4	vinutá pružina 4	1	
042	415541-7	táhlo vypínace	1	
043	645253-0	kondenzátor	1	
044	687069-7	suport JN1601	1	
045	682540-6	ochr. pruchodka 9,3-90=old682	1	
046	665890-4	prívodní kabel 1.0-2-4.0	1	
047	*****	*****	***	*****
048	265995-6	šroub 4x18 = old 265941-9	2	
049	415540-9	kryt vypínace	1	
050	266053-1	šroub 4x35=new266351-3	2	
A01	*****	*****	***	*****
A02	783208-8	klíč imbus 2.5	1	
E01	654531-7	Terminal Block 2P	1	
E04	654128-2	EARTH TERMINAL	1	

SERVICE DRAWING

MODEL NO. JN1601

